



SterileSorb™

Sterile hydroentangled cellulose/polyester wipes

Description

SterileSorb wipes are made from nonwoven fabric comprised of a hydraulically entangled blend of 55% cellulose and 45% polyester staple fibers. SterileSorb wipe is strong and durable, even when wet, and is low in extractable residues. SterileSorb wipe has outstanding sorbency and is an excellent all-purpose wipe.

Features and Benefits

- Excellent general purpose wipe
- Low levels of particles and residues
- Extremely absorbent
- Sterile per AAMI Guidelines
- Double bagged, peelable outer bag

Technical Data

Attribute; (units)	Value **	Test Method
Basis weight; (g/m ²)	70	
Sorbency in water		
Intrinsic; (mL/g)	4.03	IEST-RP-CC004.2, Sec. 7.1
Extrinsic; (mL/m ²)	281	IEST-RP-CC004.2, Sec. 7.1
Sorptive rate; (seconds)	<1	
Non-volatile residue, NVR		IEST-RP-CC004.2, Sec. 6.1.2
In deionized water; (g/m ²)	0.007	
In isopropanol; (g/m ²)	0.003	
Specific ions		IEST-RP-CC004.2, Sec. 6.2.2
Sodium; (ppm)	30.8	
Chloride; (ppm)	20.3	
Particles, readily releasable		IEST-RP-CC004.2, Sec. 5.1
P ≥ 0.5µm; (x10 ⁶ /m ²)	21.5	
Fibers > 100µm; (x10 ³ /m ²)	37.7	IEST-RP-CC004.2, Sec. 5.2

** ND = None detected; levels are below detection limit of test equipment

Part Number	Description	Packaging
C2-99IR/25	SterileSorb Wipe, 9" x 9" (23 x 23cm), Sterile	25 wipes/inner bag; 6 inner bags /outer bag; 10 outer bags/case
C2-1212IR	SterileSorb Wipe, 12" x 12" (30 x 30cm), Sterile	25 wipes/inner bag; 6 inner bags /outer bag; 7 outer bags/case

Notes:

- 1) The information presented here is applicable to the part numbers shown above as well as to any product containing the same materials and produced under the same conditions, regardless of product size or packaging configuration. Please contact a Contec sales representative for more details.
- 2) Data shown are typical values and should not be used as product specifications.
- 3) Valid product comparisons may only be obtained through side-by-side testing in the same test facility, under similar conditions.
- 4) Current and/or comparison data may be available. Please contact a Contec sales representative for details.

Revision date: 02/15/11
ETR 1610



Copyright © 2011 Contec, Inc. All rights reserved.

North America
P.O. Box 530
Spartanburg, SC 29304 USA
Phone: +1-864-503-8333
www.contecinc.com

Europe
Zl du Prat – RP 3707
56037 VANNES Cedex
FRANCE
+33 297 437 690

China
No.17 Longyun Road
Suzhou 215024
CHINA
+ 86-512-6274 4050